



Oil Service Tools

AOT-00075

Universal Oil Funnel Set (For America Cars)



Features :

- Screw-on type oil funnel prevents unsafe oil spills.
- Transparent lower chamber clearly shows oil flow process.
- Large oil passage allows oil to be refilled more rapidly.
- Includes adapters for most common vehicles in North America.
- Provided with a storage holder and a drain plate.

Specifications :

Part	Descriptions	Specifications
FN	Funnel	Opening: Ø4.9" / Ø125mm
CS	Chamber for Chrysler	Threads: M31
FR	Chamber for Ford / Mazda	Threads: M33.5
GM	Chamber for GM	Threads: M35.3
HD	Chamber for Honda	Threads: M33XP3.5
TY	Chamber for Toyota / Lexus	Threads: M37XP3.0
SB	Adapter (yellow)	Threads: M42XP4.5
RA	Adapter (red)	Threads: M37XP3.0; Clip: Ø1.2" / Ø30mm
EA	Extended Adapter	Threads: M32XP3.5; 150 degree angle

Instructions:

Use funnel and chambers

1. Choose a suitable chamber.
2. Connect the chamber to funnel.
3. Connect the chamber to oil filler neck on car (Fig.1).

Use Funnel, chambers and adapters

1. Choose a suitable adapter.
2. Connect the adapter to a suitable chamber.
 - Adapter yellow (SB) and extended adapter (EA) connect to chamber for Honda (HD)
 - Adapter red (RA) connects to chamber for Toyota/Lexus (TY)
3. Connect the adapter to oil filler neck on car (Fig.2).



AIRPRO INDUSTRY CORP.

6F-2 No.158 Kancheng Rd., Panchiao District, New Taipei City, Taiwan 22061

E-mail: sales@airprottool.com / sales@airprowu.com

Tel No : 886-2-29504785 Fax No : 886-2-89533145

www.airprottool.com Skype : airprottool





Oil Service Tools

AOT-00076

Universal Oil Funnel Set (For Europe Cars)



Features :

- Screw-on type oil funnel prevents unsafe oil spills.
- Transparent lower chamber clearly shows oil flow process.
- Large oil passage allows oil to be refilled more rapidly.
- Includes adapters for most common European vehicles.
- Provided with a storage holder and a drain plate.

Specifications :

Part	Descriptions	Specifications
FN	Funnel	Thread: M55XP1.25
FT	Chamber for Fiat	Thread: M33XP3.5
FR	Chamber for Ford/Mazda	Thread: M33.5
HD	Chamber for Honda	Thread: M32XP3.5
TY	Chamber for Toyota / Lexus	Thread: M37XP3.0
EA	Extended Adapter	Thread: M32XP3.5; 150 degree angle
VW	Adapter (black)	Thread: M37XP3.0; Clip: Ø1.3" / Ø34mm
RA	Adapter (red)	Thread: M37XP3.0; Clip: Ø1.2" / Ø30mm
SB	Adapter (yellow)	Thread: M42XP4.5
PC	Bottle Piercer	Filter: 20 mesh, Height: 2.9" / 74mm

Instructions:

Use funnel and chambers

1. Choose a suitable chamber.
2. Connect the chamber to funnel.
3. Connect the chamber to oil filler neck on car (Fig. 1).

Use funnel, chambers and adapters

1. Choose a suitable adapter (Fig. 2).
2. Connect the adapter to a suitable chamber.
 - Adapter black (VW) and red (RA) connect to chamber for Toyota/Lexus (TY)
 - Extended adapter (EA) and adapter yellow (SB) connect to chamber for Honda (HD)
3. Connect the adapter to oil filler neck on car (Fig. 3).

Use bottle piercer

1. Connect a suitable chamber to the funnel.
2. Connect the piercer to funnel.
3. Oil can be refilled by putting a new bottle upside down and directly to piercer (Fig. 4).



AIRPRO INDUSTRY CORP.

6F-2 No.158 Kancheng Rd., Panchiao District, New Taipei City, Taiwan 22061

E-mail: sales@airprottool.com / sales@airprowu.com

Tel No : 886-2-29504785 Fax No : 886-2-89533145

www.airprottool.com Skype : airprottool

